

25mm aluminium blinds

Thank you for purchasing a 25mm Aluminium blind. Your new blind has been custom built for you from the highest quality materials.

TOOLS NEEDED FOR INSTALLATION

- . Measuring tape
 - . Pencil
 - . Power drill
- Wood screws supplied.

- 1 Remove blind from package.
Contents of your hardware package will consist of brackets & screws.
- 2 For the blind to be installed correctly brackets are to be installed 100mm from each end and evenly throughout the rest of the blind. Please ensure brackets are all in line with each other.
- 3 Using a pencil mark the two screw holes on every bracket.
- 4 To ensure timber does not crack drill a small pilot hole in the middle of every marking.
- 5 Use the screws supplied to fix brackets to the window frame.
- 6 To install the blind you need to hold the blind and with the front of the blind touching the front of the brackets on an angle.
- 7 Push the back of the blind onto the rear of the bracket and ensure the lip of the bracket hooks underneath the rear lip. When you hear a click the blind has been installed correctly.
- 8 OPERATING THE BLIND.

Tilting the slats.

Rotate the wand to tilt the slats to the desired angle. Raising and lowering the blind.

- Pull the single cord down to raise and lower.
- Holding the chord tug on the plastic lever to raise and drop the blind.
- When raising and lowering the blind ensure blind is in fully open position so it can go up and down with ease.

HOW TO REMOVE THE BLIND

Firstly you must raise the blind.

Push against the front of the head rail to allow it to release the rear lip from the brackets. This will allow blind to be removed from the front of the brackets.

NEW TIMBER BLINDS INSTRUCTIONS:

Your blinds come with two end brackets.

- One is marked with LH which means this is your left hand bracket.
- The other is marked with RH. This is your right hand bracket.
- The bracket has a latch which needs to be opened upwards.

The following steps must to be taken to ensure a successful installation:

- Attach the end brackets flush against the sides of the window architrave if outside mount, or
- Against the sides of the window casement, if inside mount.
- Place brackets in position at the end of blind where it is to be installed.
- Mark the drill holes with a pencil.
- For inside mount mark the top holes in the bracket. Then pre-drill the holes where the screws will go into the architrave of the window.
- For outside mount mark the holes in the middle of the bracket. Then pre-drill the holes where the screws will go into the architrave of the window.

Intermediate bracket

If your blind is large, you will require intermediate brackets.

As part of cheapblinds.com.au service, we have supplied an intermediate bracket to ensure stability of your large blind.

- Screw the intermediate bracket, approximately in the middle of the blind into your window architrave (outside mounting) or (if inside mounting) in the window casement, to stop it from sagging and to support the blind.

When you have installed both brackets onto architrave (if outside mounting) or into window frame if inside mounting, then you are ready to install the blind.

- Holding the blind from the underneath place the headbox of blind into the brackets.
- To secure the blind you need to close the bracket latch, and ensure it is closed and locked into position before you pull the cords to release the blind.
- When both brackets have been securely locked into position it is safe to lower the blind.

SAFETY CLEAT INSTALLATION

Screw cleat at minimum height of 1600mm from the floor. Be sure to fix each cleat with 2 screws. Wrap Excess cord around cleat.

To install the valance

- Pass clips through the inside of the valance.
- Place clips on either side of valance and evenly throughout.
- Then hang the valance on the top of the headbox so it can hide the headbox.
- Push in the clips so it is securely on the blind.

Cleaning of the blind

Dust regularly with a soft cloth.