

25mm aluminium blinds

Thank you for purchasing a 25mm Aluminium blind. Your new blind has been custom built for you from the highest quality materials.

TOOLS NEEDED FOR INSTALLATION

- . Measuring tape
 - . Pencil
 - . Power drill
- Wood screws supplied.

- 1 Remove blind from package.
Contents of your hardware package will consist of brackets & screws.
- 2 For the blind to be installed correctly brackets are to be installed 100mm from each end and evenly throughout the rest of the blind. Please ensure brackets are all in line with each other.
- 3 Using a pencil mark the two screw holes on every bracket.
- 4 To ensure timber does not crack drill a small pilot hole in the middle of every marking.
- 5 Use the screws supplied to fix brackets to the window frame.
- 6 To install the blind you need to hold the blind and with the front of the blind touching the front of the brackets on an angle.
- 7 Push the back of the blind onto the rear of the bracket and ensure the lip of the bracket hooks underneath the rear lip. When you hear a click the blind has been installed correctly.
- 8 OPERATING THE BLIND.

Tilting the slats.

Rotate the wand to tilt the slats to the desired angle. Raising and lowering the blind.

- Pull the single cord down to raise and lower.
- Holding the chord tug on the plastic lever to raise and drop the blind.
- When raising and lowering the blind ensure blind is in fully open position so it can go up and down with ease.

HOW TO REMOVE THE BLIND

Firstly you must raise the blind.

Push against the front of the head rail to allow it to release the rear lip from the brackets. This will allow blind to be removed from the front of the brackets.

