

46mm lacquered cedar venetian blinds

Thank you for purchasing a 46mm Lacquered Cedar Venetian blind. Your new blind has been custom built for you from the highest quality materials.



Image 1

TOOLS NEEDED FOR INSTALLATION

- .Measuring tape
- .Pencil
- .Power drill
- .Wood screw supplied

SPECIAL HINT

PLEASE ENSURE ALL BRACKETS ARE LEVEL AND IN LINE WITH EACH OTHER.

- 1 Remove blind from package.
- 2 Have a look at the inside of the blind to give you an idea of the location of its inside componentry.
- 3 Place brackets 170 mm from each end of the blind.
- 4 Place middle brackets between the ladders in order that there is no interference to the workings of the blind.
- 5 Use the pencil to mark to screw holes on each bracket.
- 6 Drill a small pilot hole in the middle of each pencil marking.
- 7 Fix the brackets in place with the screws supplied.
- 8 To install the blind grab the front of the blind and place in front of the front bracket.
- 9 With the rear of the blind push the blind to ensure it hooks under the rear lip. (refer to image 2)
- 10 Once the blind is installed please install the valance to give it the completed look.



Image 2

OPERATING THE BLIND

Tilting the slats: The two cords with individual tassels are for tilting the slats. Each cord tilts the slats in an alternative direction.

Raising and lowering the blind: Pull the single cord down and toward the centre to raise and lower. The slats should be open when raising and lowering. Hold the cord to the outside to lock the blind in position.



CARE AND CLEANING

Easily cleaned with warm soapy water.

Dust regularly. use a soft clean cloth. lower the blind to its full length, tilt the slats almost all the way down and dust. Then tilt the slats almost all the way up and dust.

Image 3

NEW TIMBER BLINDS INSTRUCTIONS:

Your blinds come with two end brackets.

- One is marked with LH which means this is your left hand bracket.
- The other is marked with RH. This is your right hand bracket.
- The bracket has a latch which needs to be opened upwards.

The following steps must to be taken to ensure a successful installation:

- Attach the end brackets flush against the sides of the window architrave if outside mount, or
- Against the sides of the window casement, if inside mount.
- Place brackets in position at the end of blind where it is to be installed.
- Mark the drill holes with a pencil.
- For inside mount mark the top holes in the bracket. Then pre-drill the holes where the screws will go into the architrave of the window.
- For outside mount mark the holes in the middle of the bracket. Then pre-drill the holes where the screws will go into the architrave of the window.

Intermediate bracket

If your blind is large, you will require intermediate brackets.

As part of cheapblinds.com.au service, we have supplied an intermediate bracket to ensure stability of your large blind.

- Screw the intermediate bracket, approximately in the middle of the blind into your window architrave (outside mounting) or (if inside mounting) in the window casement, to stop it from sagging and to support the blind.

When you have installed both brackets onto architrave (if outside mounting) or into window frame if inside mounting, then you are ready to install the blind.

- Holding the blind from the underneath place the headbox of blind into the brackets.
- To secure the blind you need to close the bracket latch, and ensure it is closed and locked into position before you pull the cords to release the blind.
- When both brackets have been securely locked into position it is safe to lower the blind.

SAFETY CLEAT INSTALLATION

Screw cleat at minimum height of 1600mm from the floor. Be sure to fix each cleat with 2 screws. Wrap Excess cord around cleat.

To install the valance

- Pass clips through the inside of the valance.
- Place clips on either side of valance and evenly throughout.
- Then hang the valance on the top of the headbox so it can hide the headbox.
- Push in the clips so it is securely on the blind.

Cleaning of the blind

Dust regularly with a soft cloth.