

46mm lacquered cedar venetian blinds

Thank you for purchasing a 46mm Lacquered Cedar Venetian blind. Your new blind has been custom built for you from the highest quality materials.



Image 1

TOOLS NEEDED FOR INSTALLATION

- .Measuring tape
- .Pencil
- .Power drill
- .Wood screw supplied

SPECIAL HINT

PLEASE ENSURE ALL BRACKETS ARE LEVEL AND IN LINE WITH EACH OTHER.

- 1 Remove blind from package.
- 2 Have a look at the inside of the blind to give you an idea of the location of its inside componentry.
- 3 Place brackets 170 mm from each end of the blind.
- 4 Place middle brackets between the ladders in order that there is no interference to the workings of the blind.
- 5 Use the pencil to mark to screw holes on each bracket.
- 6 Drill a small pilot hole in the middle of each pencil marking.
- 7 Fix the brackets in place with the screws supplied.
- 8 To install the blind grab the front of the blind and place in front of the front bracket.
- 9 With the rear of the blind push the blind to ensure it hooks under the rear lip. (refer to image 2)
- 10 Once the blind is installed please install the valance to give it the completed look.



Image 2

OPERATING THE BLIND

Tilting the slats: The two cords with individual tassels are for tilting the slats. Each cord tilts the slats in an alternative direction.

Raising and lowering the blind: Pull the single cord down and toward the centre to raise and lower. The slats should be open when raising and lowering. Hold the cord to the outside to lock the blind in position.



CARE AND CLEANING

Easily cleaned with warm soapy water.

Dust regularly. use a soft clean cloth. lower the blind to its full length, tilt the slats almost all the way down and dust. Then tilt the slats almost all the way up and dust.

Image 3