

sunscreen & holland blinds

Thank you for purchasing Sunscreen & Holland blinds. Your new blind has been custom built for you from the highest quality materials.

Remove the blind from the package. The installation brackets are supplied in pairs. One bracket is used with the control side of the blind (the side with the chain) and the second bracket is used with the rotator side.



The installation brackets are always mounted so that the inner surfaces face each other. It is very important that the brackets are mounted so that the blind is level when installed.



INSIDE MOUNT

Have a look at your blind and see where you ordered the control side to be on.



- 1 Take the bracket with the protrusion (the side where the chain drive is on) and look carefully at your window. Hold the bracket to the spot on your window where it is to be fixed. Please ensure you have allowed enough gap between the glass and the bracket. Look at image on left.



- 2 With a pencil please mark the two screw holes on each bracket.
- 3 Drill a small hole in the middle of each marking to help the screws in.
- 4 Fix the brackets to the window with screws provided. (wood screw provided)
- 5 Grab the blind and install the chain drive end into the bracket with the protrusion.

VERY IMPORTANT

Please ensure the blind is installed into the bracket with the two markings on top of the chain drive facing upward.

- 6 Hold the blind in position. Now we need to place the other end of the blind into the track of the other bracket until it clicks into position.

WARNING FOR PARENTS. Children could accidentally strangle in the window covering cords. Keep the chain cord out of reach of children with the tension device provided. The tension device reduces the hazards of strangulation and entanglement of young children by limiting access to the control cord. Anchor the tension device to the window frame or wall preventing children from wrapping the cord around their necks.

- 7 Position the tension device on the window frame or the wall so that the tension device and the chain do not interfere with raising or lowering the blind. The chain must be taut, but still operable, do not allow for any slack. Do not twist or cross the chain. Holding the tension device upright and in position insert and secure the screw into the hole. Your blind is finally installed. To open or close the blind it now can be operated by the chain.



OUTSIDE MOUNT

SAME AS ABOVE EXCEPT PLACE BRACKETS ON EITHER END OFF WINDOW CORNER ARCHITRAVES.

NEW TIMBER BLINDS INSTRUCTIONS:

Your blinds come with two end brackets.

- One is marked with LH which means this is your left hand bracket.
- The other is marked with RH. This is your right hand bracket.
- The bracket has a latch which needs to be opened upwards.

The following steps must to be taken to ensure a successful installation:

- Attach the end brackets flush against the sides of the window architrave if outside mount, or
- Against the sides of the window casement, if inside mount.
- Place brackets in position at the end of blind where it is to be installed.
- Mark the drill holes with a pencil.
- For inside mount mark the top holes in the bracket. Then pre-drill the holes where the screws will go into the architrave of the window.
- For outside mount mark the holes in the middle of the bracket. Then pre-drill the holes where the screws will go into the architrave of the window.

Intermediate bracket

If your blind is large, you will require intermediate brackets.

As part of cheapblinds.com.au service, we have supplied an intermediate bracket to ensure stability of your large blind.

- Screw the intermediate bracket, approximately in the middle of the blind into your window architrave (outside mounting) or (if inside mounting) in the window casement, to stop it from sagging and to support the blind.

When you have installed both brackets onto architrave (if outside mounting) or into window frame if inside mounting, then you are ready to install the blind.

- Holding the blind from the underneath place the headbox of blind into the brackets.
- To secure the blind you need to close the bracket latch, and ensure it is closed and locked into position before you pull the cords to release the blind.
- When both brackets have been securely locked into position it is safe to lower the blind.

SAFETY CLEAT INSTALLATION

Screw cleat at minimum height of 1600mm from the floor. Be sure to fix each cleat with 2 screws. Wrap Excess cord around cleat.

To install the valance

- Pass clips through the inside of the valance.
- Place clips on either side of valance and evenly throughout.
- Then hang the valance on the top of the headbox so it can hide the headbox.
- Push in the clips so it is securely on the blind.

Cleaning of the blind

Dust regularly with a soft cloth.