

# sunscreen & holland blinds

Thank you for purchasing Sunscreen & Holland blinds. Your new blind has been custom built for you from the highest quality materials.

Remove the blind from the package. The installation brackets are supplied in pairs. One bracket is used with the control side of the blind (the side with the chain) and the second bracket is used with the rotator side.



The installation brackets are always mounted so that the inner surfaces face each other. It is very important that the brackets are mounted so that the blind is level when installed.



## INSIDE MOUNT

Have a look at your blind and see where you ordered the control side to be on.



- 1 Take the bracket with the protrusion (the side where the chain drive is on) and look carefully at your window. Hold the bracket to the spot on your window where it is to be fixed. Please ensure you have allowed enough gap between the glass and the bracket. Look at image on left.



- 2 With a pencil please mark the two screw holes on each bracket.
- 3 Drill a small hole in the middle of each marking to help the screws in.
- 4 Fix the brackets to the window with screws provided. (wood screw provided)
- 5 Grab the blind and install the chain drive end into the bracket with the protrusion.

## VERY IMPORTANT

Please ensure the blind is installed into the bracket with the two markings on top of the chain drive facing upward.

- 6 Hold the blind in position. Now we need to place the other end of the blind into the track of the other bracket until it clicks into position.

**WARNING FOR PARENTS.** Children could accidentally strangle in the window covering cords. Keep the chain cord out of reach of children with the tension device provided. The tension device reduces the hazards of strangulation and entanglement of young children by limiting access to the control cord. Anchor the tension device to the window frame or wall preventing children from wrapping the cord around their necks.

- 7 Position the tension device on the window frame or the wall so that the tension device and the chain do not interfere with raising or lowering the blind. The chain must be taut, but still operable, do not allow for any slack. Do not twist or cross the chain. Holding the tension device upright and in position insert and secure the screw into the hole. Your blind is finally installed. To open or close the blind it now can be operated by the chain.



## OUTSIDE MOUNT

SAME AS ABOVE EXCEPT PLACE BRACKETS ON EITHER END OFF WINDOW CORNER ARCHITRAVES.