

sunscreen & holland blinds

**We urge you to read these measuring instructions before making your order.
We cannot exchange your order or refund you for blinds that were not measured correctly.**

- Always use a steel tape measure for all measurements.
- The width is always the first measurement recorded.
- Always measure every window, even if you think the windows are the same. Our blinds are custom made to fit, therefore each window must be measured individually.
- Record all measurements in millimetres.
- Please measure window exactly, as we will make adjustments for brackets.

What is INSIDE MOUNT?

Inside mount refers to a blind that will be installed inside a window frame or encasement, where the window is recessed and the blind will hang inside the window frame/encasement.

What is OUTSIDE MOUNT?

Outside mount refers to blinds that will be installed outside the window frame and overlap the window frame. Please note outside mount blinds will cover the window and will provide the most light blockage and privacy. Cheapblinds.com.au will not take any deductions from an outside mount blind. The blind will be manufactured to the exact measurements specified.

How to measure INSIDE MOUNT?

To fit inside the window recess;


- Measure the exact width inside from left to right of the window recess at the top (**A**).
- Please write this down.

THIS IS THE WIDTH YOU WILL ORDER.

- Measure the exact height inside from bottom to top of the window at left (**D**), middle (**E**) & right (**F**).
- Then record the longest of the heights on the form.

THIS IS THE HEIGHT YOU WILL ORDER.

Cheapblinds.com.au will make the necessary deductions or additions to the height measurement and width measurement for you.



Inside Mount

- If you choose to **back-roll** your blind, you require 60mm clearance from the frame to accommodate for the fabric and roll tube.
- If you choose to **front-roll** your blind, you only require 20mm clearance from the frame to accommodate for the fabric & roll tube.


Width measurement – you only need to measure the top inside measurement, as this is where the brackets will be mounted.

Height measurement – you will need to measure the height on either ends of your window and record the largest measurement.

Handy Hint – always keep an eye out for any knobs or handles which may obstruct the blind, if there are any obstructions it is preferable to mount your blind on the outside of your window frame.

How to measure OUTSIDE MOUNT?

- Measure the width you require from side to side of the window at **top (a)**. Then record this measurement.
- Measure the height you require from bottom to top of the window at **left (D)**, **middle (E)** and **right (F)**. Then record the longest of the lengths on the form.

**Outside Mount**

You still have the choice to either **back-roll** or **front-roll**. If you choose the back-roll the blind will be closer to your window providing you maximum privacy.

Width measurement – you need to measure the top outside frame from the top left hand corner to the right hand corner of your window frame

Height measurement – you need to measure the height on either side of your window and record the largest measurement.